

How To Use

Hot-Rod

Mount the Alpha® Hot-Rod blade onto the Alpha® AWS-110/AWS-125 Wet Stone Cutter, making sure the directional rotation marked on the blade matches the spindle rotation of the power tool.

Attach the Guide Ruler accessory of the Alpha® AWS-110 Stone Cutter so the ruler guide is following the edge of stone as a guide. Using the Guide Ruler will assure your channel is cut straight to allow the reinforcement rod to fit easily.

Adjust the depth of the cut so the Hot-Rod blade cuts deep enough so the reinforcement rod is below the surface of the material. The rod should be lower than the surface of the material to allow the adhesive to cover the rod to prevent oxidation.

Using a lumber crayon, draw a line on the material so you know the length needed for the reinforcement rod.

Plunge the blade into the material until the base of the Stone Cutter makes full contact with the material. Once the Alpha® Hot-Rod blade is fully plunged into the material, push the blade through the material to the desired length required to install the reinforcement rod. (NOTE: To start plunge cutting, we suggest resting the edge of the base plate of the Stone Cutter onto the material before plunging into the material. Doing so will give you better stability during your plunge cut).

(Consult the power tool operation manual for proper installation instructions for mounting blades).