

Helpful Hints

Q-Cut

- Do not force the blade to cut. Allow the diamonds to perform cutting through the material. Slower cutting helps eliminate chipping on the cut edge.
- For thick material (3cm or 1-1/4") step-cutting is highly recommended.
- Wet cutting is required for the larger blade sizes (6", 8" and 10").
- Take appropriate steps to assure personal safety when performing any cutting application.
- Review operations manual of the power tool to assure proper usage.