

Helpful Hints

Profiler Z-Series

- Use of a C-Shape handle is recommended for this application. Alpha® Profilers are WET USE ONLY for LOW-SPEED applications. Do not allow the nylon guide to free-spin during application as scratches on the surface of material may occur from slurry residue. The Alpha Professional Tools® logo on the nylon guide should be clearly displayed during profiling application when using the Alpha® Profiler correctly.
- Use plenty of water during application. Use of water will flush away excess slurry from surface.
- For proper use of the Alpha® Profilers, see attached "How To Use".
- Use of a Plexiglas template mounted on top of a sink bowl cut-out will assure a smooth ripple-free edge. The Profiler's ball bearing/rotary touchier will follow the Plexiglas while the vacuum brazed diamonds of the profiler will grind away the excess stone material to achieve a consistent desired shape when using the Alpha® Profiler Z Series.