

## **Helpful Hints**

## Vetro

- Do not force the blade to cut; allow the diamonds time to cut through the material. Slower cutting helps eliminate chipping on the cut edge.
- Wet cutting is required.
- Review operations manual of the power tool to assure proper usage.
- Placing a piece of thin Styrofoam or 1/8" plywood under the glass can provide a cushion which can be helpful in eliminating chipping.
- Use Alpha® PVA (Red & Blue) to ease and polish the edge of glass tiles.
- Use the Alpha® Corner Nippers and Alpha® Corner Rulers for other glass applications.
- Take appropriate steps to assure personal safety when performing any cutting application.