

Helpful Hints

Ecocutter

- Make sure the inner belt and outer belt is functioning correctly. These belts drive the pulleys for the fan exhaust that forces the air flow into the dust bag.
- Take care to ensure that the cutting area is clear of debris and no one will be in a position to interfere with the cutting application.
- Attach side handle for better stability during cutting applications.
- Have an extra set of belts (inner and outer) on hand.
- When using the Ecocutter with the Alpha® Ecocutter Table and Stand, refer to the Dry Tile Cutting System Instruction Manual for proper setup and usage.