

Helpful Hints

Cordless Saw Blade for Glass

- In order to maintain proper speed, always make certain to use a fully charged battery.
- Do not force the blade to cut; allow the diamonds time to cut through the material. Slower cutting helps eliminate chipping on the cut edge.
- Wet cutting is required.
- Take appropriate steps to assure personal safety when performing any cutting application
- Review operations manual of the power tool to assure proper usage.
- Use the Alpha® Corner Nippers and Alpha® Corner Rulers for other glass applications.
- Use Alpha® PVA (Red & Blue) to ease and polish the edge of glass tiles.