

How To Use

Sonic

Attach the Alpha® Sonic blade onto your tub saw or tile saw making sure that the blade's directional arrows match the spindle rotation of your power tool. Adjust the depth of your cut; generally if the blade is 1/8" below the material you are cutting, this is sufficient. Make sure your power tool has ample supply of water for cooling the blade during application. Turn on the power of your tub or tile saw and slowly push the blade into the material, maintaining a consistent slow traverse speed until you cut through the entire piece of material. A slow consistent pushing motion allows the diamonds within the blade's cutting edge to cut the material easily and minimize chipping on the edge.