

How To Use

Porcellana for Portable Rail Saw

Attach the Alpha® Porcellana blade on your portable rail saw making sure that the directional arrows on the blade and spindle match the rotation of your power tool. Adjust the depth of your cut; generally, if the blade is 1/8" below the material you are cutting, this is sufficient. Make sure your saw has an ample supply of water for cooling the blade during application. Turn on power and slowly pull the blade into the material maintaining a consistent slow traverse speed until you cut through the entire piece of material. A slow consistent pulling motion will allow the diamonds within the blade's cutting edge to cut the material easily and minimize chipping on the edge.