

Helpful Hints

Ecoguard Type W5

- When installing the Ecoguard Type W5 onto the angle grinder, make sure the Ecoguards connector assembly is pushed all the way down and sitting flush on the grinder's neck to assure the Ecoguard is in perfect alignment.
- Attaching two stainless steel hose bands to both sides of the Rubber Hose Connector will fully secure the vacuum hose so it doesn't pull out of the connector or off the Ecoguard itself. To purchase this extra stainless steel hose band (Part No. 500006), contact the Alpha® Tool Department at 800-648-7229 ext. 505.
- Tuck Point and crack chasing applications are also easier using the Alpha® Ecoguard W5 since it is transparent and you can see inside the cover while cutting due to the clear polycarbonate material construction
- Placing your material on top of Styrofoam board will assist in total dust containment. Secure the material on top of a piece of Styrofoam board and then set the cutting depth on the Ecoguard so the blade cuts one quarter of the way into the Styrofoam board. This will create a seal which will force the dust back into the Ecoguard and into the vacuum.
- Alpha® recommends using the Alpha® HEPA Vacuum with the Ecoguard W5.
<http://www.alpha-tools.com/Product.aspx?PageCode=1730>
- Video of the Ecoguard W5 can be seen on the product page by clicking the video tab.
<http://www.alpha-tools.com/Product.aspx?PageCode=1670>