

## Helpful Hints

### Ecoguard Type C

- When installing the Ecoguard C onto the angle grinder, make sure the Ecoguard's connector assembly is pushed all the way down and sitting flush on the grinder's neck to assure the Ecoguard is in perfect alignment.
- Attaching two stainless steel hose bands to both sides of the Rubber Hose Connector will fully secure the vacuum hose so it doesn't pull out of the connector or off the Ecoguard itself. To purchase this extra stainless steel hose band (Part No. 500006), contact the Alpha® Tool Department at 800-648-7229 ext. 505.
- The Alpha® 18" Flexible Connector Hose (Part No. 500026) can be purchased separately to be used with the Ecoguard Type C and Alpha® HEPA Vacuum.
- Placing your material on top of Styrofoam board will assist in total dust containment. Secure the material on top of a piece of Styrofoam board and then set the cutting depth on the Ecoguard so the blade cuts one quarter of the way into the Styrofoam board. This will create a seal which will force the dust back into the Ecoguard and into the vacuum.
- Alpha® recommends using the Alpha® HEPA Vacuum with the Ecoguard C.  
<http://www.alpha-tools.com/Product.aspx?PageCode=1730>
- Using the Alpha® Spike Ruler is highly recommend for making precise straight cuts when using the Ecoguard C <http://www.alpha-tools.com/Product.aspx?PageCode=2000>
- Video of the Ecoguard C can be seen on the product page by clicking the video tab  
<http://www.alpha-tools.com/Videos.aspx?PageCode=1520>