

## Helpful Hints

### Ecoguard Type G

- When installing the Ecoguard G onto the angle grinder, make sure the Ecoguard's connector assembly is pushed all the way down and sitting flush on the grinder's neck to assure the Ecoguard is in perfect alignment.
- Ecoguard G and the Alpha® 5" Spike Disc are a perfect combination for fiber glass removal on the backside of slabs.
- Attaching two stainless steel hose bands to both sides of the Rubber Hose Connector will fully secure the vacuum hose so it doesn't pull out of the connector or off the Ecoguard itself. To purchase this extra stainless steel hose band (Part No. 500006), contact the Alpha® Tool Department at 800-648-7229 ext. 505.
- Alpha® recommends using the Alpha® HEPA Vacuum with the Ecoguard W5.  
<http://www.alpha-tools.com/Product.aspx?PageCode=1730>
- Video of the Ecoguard W5 can be seen on the product page by clicking the video tab.  
<http://www.alpha-tools.com/Product.aspx?PageCode=1530>
- Grinder Compatibility Chart for all Ecoguards can be found on the product page or by clicking the following link: <http://www.alpha-tools.com/Files/OtherReferences/PDFs/Ecoguard-Grinder-Compatibility-Chart.pdf>
- When grinding or polishing in open areas, use the Ecoguard G with the Sub Cover attached. When grinding or polishing against baseboards, remove the Sub Cover and attach the Half Cover.
- Brushes (A & B) on the Ecoguard G create the vacuum seal during the grinding/polishing operation. Make sure when you attach the grinding/polishing wheel that the brushes make flush contact with the surface. If the grinding/polishing wheel is making contact to the surface and the brushes are not, refer to the Instruction Manual and install a thinner spacer between the grinding wheel and spindle of the power tool.