

How To Use

Vortex for Marble

Mount the Alpha® Vortex for Marble blade onto the Alpha® BAH-5/8 adapter making sure the countersunk holes drilled into the blade are facing upward. Align the hole pattern of the blade together with the hole pattern of the adapter and insert the countersunk screws. Tighten the screws, using a screwdriver, making sure the heads of the countersunk screws are level with or, below the height of the blade core.

The Alpha® Vortex for Marble blade is now ready to be mounted onto a 5" high-speed angle grinder with a 5/8" -11 threaded spindle.

Always refer to the operation manual of the power tool for correct mounting procedures.