

## How To Use

### PVA MS Style

1. Mount the PVA Makita Style onto your choice of high-speed grinder.
2. Cut work piece to size.
3. Clamp work piece securely to prevent vibration.
4. Shape edges to desired pattern with Alpha® PVA Extra Coarse (White), or other Alpha® products such as: Alpha® Profilers, Alpha® Profile Wheels or Alpha® Dry Grinding Wheels.
5. Take time to carefully prepare the work piece as much as possible. Alpha® PVA Finer Grit Wheels will not work properly over gouges, scratches and rough areas.
6. Starting with PVA Coarse (Red) lightly run the wheel over the marble. Do not push down, and don't use water.
7. Continue polishing with Medium (Blue), Fine (Green), and finally Extra-Fine (Yellow).

Refer to the power tools owner's manual for proper attachment of accessories.