


# Alpha<sup>®</sup> Ecoguard Type G Dust Collection Cover Instruction Manual



(\*Shown with angle grinder / sold separately)

Part No: ECOGRDGR  
Version 2

 **Alpha Professional Tools**<sup>®</sup>

103 Bauer Drive, Oakland, NJ 07436 • 800-648-7229 • Fax: 800-286-0114  
[www.alpha-tools.com](http://www.alpha-tools.com)

# TABLE OF CONTENTS

Introduction.....	3
About the Symbols.....	3
Ecoguard Type G Overview.....	4
Accessories .....	4
Installing the Dust Collection Cover.....	5
Installing the Connector .....	5
Mounting the Grinding Cup Wheel to the Grinder .....	8
Attachable Grinders.....	10
Grinding Applications.....	11
Surface Grinding.....	11
Wall Grinding .....	11
Attaching the Dust Collector .....	12
Ecoguard Type G Schematic.....	13
Ecoguard Type G Other Connectors and Spacers.....	14
Ecoguard Type G Parts List.....	15

# INTRODUCTION

Thank you for purchasing the Alpha® Ecoguard Type G Dust Collection Cover. The Ecoguard Type G must be used with a vacuum, or other dust collection system. To ensure correct use, read this Instruction Manual and the Instruction Manual for the power tool and follow the operating instructions. Keep this manual in a place where operators can access it easily whenever necessary!

## ► ABOUT THE SYMBOLS

According to the hazard level, all safety notes in this manual are classified into “DANGER”, “WARNING”, and “CAUTION”.

-  **DANGER!** Death or serious personal injury is imminent when handling this polisher incorrectly.
-  **WARNING!** There is a possibility of death or serious personal injury when handling this polisher incorrectly.
-  **CAUTION!** There is a possibility of personal injury or property damage when handling this polisher incorrectly.

**Note:** In some situations, failing to observe WARNING notes could result in death or serious personal injury. Be sure to read and observe the safety notes to ensure safety and correct use of the polisher.

## ► PRECAUTIONS FOR USING DUST COLLECTION COVER

1. The Dust Collection Cover is for use with a .5” (115mm), 5” (125mm) or 6” (150mm) high-speed angle grinder.
2. The Dust Collection Cover is designed for grinding concrete, stone and other masonry products. Do not use when cutting metal or other materials.
3. The Dust Collection Cover is solely designed for use with a diamond cup wheel. Do not use with any other type of blade such as a grindstone or chip saw.
4. Always check the Dust Collection Cover for damage, cracks or deformation before starting work. Do not use the Dust Collection Cover if it is damaged, cracked or bent as this could cause to injury.
5. Always wear eye protection. Dust mask, nonskid safety shoes, hard hat, or hearing protection must be used for appropriate conditions.
6. Keep the Dust Collection Cover away from gasoline, thinner, petroleum and paraffin.
7. The supplied connector may not connect securely to every high-speed angle grinder. In this case, do not use the Dust Collection Cover.

# ECOGUARD TYPE G OVERVIEW




---


## ► ACCESSORIES

Ecoguard Dust Collection Cover w/ Connector (Part# 500028) .....	1 pc
Collar .....	2 pcs
Additional Connector Assembly for Most 5" Grinders.....	2 pcs
Flanges and Lock nut Set for Selected Grinders.....	1 Set (3pcs)
Hex Wrench.....	1 pc
Rubber Hose Adapter .....	1 pc
Spacers .....	4 pcs
Stainless Steel Hose Band.....	1 pc
Pin Wrench .....	1 pc

# INSTALLING THE DUST COLLECTION COVER


**⚠ WARNING!**

1. Be sure to turn off the high-speed angle grinder and remove the plug from the electrical outlet before attaching and installing the Dust Collection Cover.
2. Take the Guard off from the Grinder



2. Make sure the Dust Collection Cover is securely attached, otherwise it may come loose which could cause injury.
3. If you installed the Dust Collection Cover to a high-speed angle grinder but the connector is loose and cannot be securely attached, do not use the Dust Collection Cover. Using it in this state could cause injury.


## ► INSTALLING THE CONNECTOR

ALPHA® / MAKITA®	BOSCH	HITACHI	METABO®	DEWALT
HSG-125	1801	G12SR3 G13SE2 & G12SS	WE9-125 Quick & W11-125 Quick	D28402 & D28131
9565CV, 9558NB				
				
(Factory Preset)				


(Fig.1)

If the different Connector is needed, exchange the connector as per the following instructions.


1. Loosen the Screws.
2. Take the front of the Connector Assembly off.




3. Loosen the Flat Head Screws using the Hex Wrench.
4. Take the back of the Connector Assembly off.
5. Replace with other Connector.
6. Place in the other Connector Assembly.



7. Tighten Flat Head Screws with Hex Wrench.  
(DO NOT forget to insert Taper Washers)



8. Tighten the Screws  
(DO NOT forget to insert Spring Washers)



**⚠ CAUTION!**


The Dust Collection Cover is solely designed for use with a grinding cup wheel. Do not use with any other type of blade, such as a cutoff or tip saw blades.

# MOUNTING THE GRINDING CUP WHEEL TO THE GRINDER


**⚠ WARNING!**


Make sure the Ecoguard Type G is securely attached to the grinder, otherwise it may come loose, causing injury.

1. Firmly hold Connector Assembly and tighten the screws.



2. Set the proper Spacer into the spindle.
3. Set the Base or Inner Flange on the Spacer.
4. Set the Grinding Cup Wheel on the Base or Inner Flange.
5. Set the Lock Nut on the Grinding Cup Wheel. (Be careful to ensure the correct direction of the Lock Nut)
6. Depress the spindle and tighten the Lock Nut with the Pin Wrench.





Reference: Example of the combination of Spacer and Base Flange

CUP Type	Parts	ALPHA®	MAKITA®		HITACHI	
		HSG-125	9565CV	9558NB	G12S43	G13SE2
(A) $h=2$ 	Flange	500029				
	Lock Nut	Original				
	Spacer	500011 / T2.5	N/A		500011 / T2.5	
(B) $h=17$ 	Flange	500029				
	Lock Nut	Original				
	Spacer	500011 / T2.5	N/A		500012 / T5.0	
(C) $h=24$ 	Flange	N/A				
	Lock Nut					
	Spacer					

CUP Type	Parts	METABO®		BOSCH	DEWALT	
		WE9-125	W11-125	1801	D28402	D28131
(A) $h=2$ 	Flange	500029			500007	
	Lock Nut	Original			500008	
	Spacer	500011 / T2.5	500012 / T5.0		N/A	
(B) $h=17$ 	Flange	500029			500007	
	Lock Nut	Original			500008	
	Spacer	500012 / T5.0	500013 / T7.0		500011 / T2.5	
(C) $h=24$ 	Flange	N/A				
	Lock Nut					
	Spacer					

Cup Type C does not need Drawing No. 12/Base Flange

# ATTACHABLE GRINDERS


GRINDER	SIZE	MODEL	GRINDER	SIZE	MODEL	GRINDER	SIZE	MODEL		
ALPHA®	5"	HSG-125			1800			D28110		
MAKITA	4-1/2"	GA4530	BOSCH	4-1/2"	1810PS	DEWALT	4-1/2"	D28112		
		GA4534			1810PSD			D28402		
		9564CV			1801			D28065		
		9564PC		1803EVS	4-1/2" / 5"		D28114			
		9557NB		1811PS	D28115					
		9557PB		1821	D28131					
		GA5010Z		1821D	6"		D28140			
	GA5020	1806E		D28144						
	GA5020Y	1812PSD								
	9558PB	W8-115		MILWAUKEE	4-1/2"		6130-33			
	9565CV	W8-115 Quick	6140-30							
	9565PC	W8-115 QuickProtect	6146-30							
	GA6020	W8-125 Quick	6146-31							
	GA6010Z	W11-125 Quick	6146-33							
	9566CV	WA11-125 Quick	6147-30							
	9566PC	WE9-125 Quick	6147-31							
	HITACHI	4-1/2"	G12SA3			METABO	5"	WE14-125 Plus	5"	6121-30
			G12SE2					WE14-125 VS		6121-31
G12SE2P9			WP8-125 QuickProtect					6117-30		
G12SVA			WP11-125 QuickProtect					6117-31		
G12SR3			WEPA14-125 QuickProtect					6117-33		
G12SS			W11-150 Quick					6117-33D		
5"		G13SC2	WE14-150 Quick				6"	6121-31A		
		G13SC2P9	WEP14-150 QuickProtect	6124-30						
		G13SP	WEPA14-150 QuickProtect	6124-31						
		G13VA	WP11-150 QuickProtect	6161-30						
							6161-31			
							6161-33			

# GRINDING APPLICATIONS

## ► SURFACE GRINDING


Securely connect the Flexible Connector Hose to the Dust Collection Cover. Turn Grinder and Vacuum on to start grinding application.

Use the Alpha® Rubber Hose Connector as a joint between duct and Flexible Connector Hose.




## ► WALL GRINDING

1. Loosen the screws and remove the Sub Cover and Half Cover.




2. Switch the position of the Sub Cover and Half Cover.
3. Tighten screws.




## ATTACHING THE DUST COLLECTOR

1. Securely connect Flexible Connector Hose to the duct of the grinder, then turn Grinder and Vacuum Cleaner on to start grinding application.
2. Use an adapter such as the Alpha® Rubber Hose Connector as a joint between the duct and the Flexible Hose Connector.







# ALPHA® ECOGUARD TYPE G SCHEMATIC



\*Original indicates Lock Nut included with tool.

# ECOGUARD TYPE G OTHER CONNECTORS AND SPACERS

HITACHI	METABO	BOSCH	DEWALT
 <p>10-b</p> <p>11</p> <p>12-a</p> <p>Original Lock Nut*</p>	 <p>10-c</p> <p>13</p> <p>11</p> <p>12-a</p> <p>Original Lock Nut*</p>	 <p>10-c</p> <p>11</p> <p>12-b</p> <p>16</p>	 <p>14</p> <p>10-c</p> <p>11</p> <p>12-b</p> <p>16</p>

\*Original indicates Lock Nut included with Tool.

# 11-a,b,c,d - Choose spacer according to Cup Type. (See chart on page 10)

# ALPHA® ECOGUARD TYPE G PARTS LIST

DRAWING NO.	PART NO.	DESCRIPTION	QUANTITY
1	500032	Main Cover	1
2	500033	Sub Cover	1
3	500034	Half Cover	1
4	500005	Rubber Hose Adapter	1
5	500006	Stainless Steel Hose Band	1
6	500037	Screw M4x10	4
7	500038	Set Plate	1
8	500039	Holder Spring	4
9	500020	Flat Head Screw M4x5	3
10a	500028	Connector Assembly (Alpha®/Makita®)	1
10b	500003	Connector Assembly (Hitachi)	1
10c	500004	Connector Assembly (Metabo®/Bosch /Dewalt)	1
11a	500011	Spacer / T2.5	1
11b	500012	Spacer / T5.0	1
11c	500013	Spacer / T7.0	1
11d	500014	Spacer / T9.4	1
12a	500029	Base Flange	1
12b	500007	Inner Flange	1
13	500022	Collar M (Metabo)	1
14	500035	Collar D (Dewalt)	1
16	500008	Lock Nut	1
17	500024	Hex. Wrench	1
18	210105	Pin Wrench	1
19	500036	Seal	1
20	500040	Brand Label	1
21	500041	Brush (A)	1
22	500042	Brush (B)	1
23	500021	Taper Washer	3
<b>Optional Accessory:</b>			
Shown on pg 4	500026	Flexible Connector Hose 18"	1



103 Bauer Drive, Oakland, NJ 07436 • 800-648-7229 • Fax: 800-286-0114  
[www.alpha-tools.com](http://www.alpha-tools.com)

Copyright © 2012 Alpha Professional Tools. All rights reserved.

04/2012

---